



ELCA
PROFESSIONAL LIGHTING

INSTALLATION INSTRUCTIONS

Downlight Prime Series



Power	Volt	IP
7 W	220 VAC	20


Electrical
- 220 VAC

Requirements


- Holesaw (Matabor)
- Wire Connector

Dimension - 7 W

Downlight Prime MR16




Downlight Prime Series



Constant Current Driver - On/Off Installation

220 VAC
(Neutral)
(Line)



PERINGATAN

1. Ikuti petunjuk instalasi, garansi tidak berlaku jika instalasi tidak sesuai dengan petunjuk
2. Pastikan sumber listrik mati sebelum pemasangan instalasi lampu
3. Dilarang membuka komponen isi lampu, garansi tidak berlaku jika lampu telah dibuka